

How to install ITX Chassis No.2600 Front IR

1. Required software on Mini-ITX M/B
ET-BIOS
2. Required hardware about system
 - *IR receiver module
 - *Connected IDE cable from IR module to M/B
 - *Remove-controller or IR keyboard

Please note:

ET-BIOS software is not the same for all the Mini-ITX M/B. It depends on the North Bridge Chipset. If the North Bridge Chipset is different, the ET-BIOS will be also different.

(For example, the North Bridge Chipset of EPIA-M & EPIA-SP are different, so the ET-BIOS for them are also different)